

(Cont. next page)
53 LAND CRUISER / LAND CRUISER PRADO
Power Source
Audio System (Separate Type Amplifier)
* 1 : 1GR–FE
* 2 : Except 1GR–FE
* 3 : 2TR–FE
* 4 : Except 2TR–FE
C 4
CD Automatic Changer
R 2(A), R 3(B)
Radio and Player
A40
Antenna Amplifier
J20
Junction
Connector
I14
Ignition SW
ACC
IG1
ST1
AM1
7. 5A
ACC
ACC CUT
Relay
Engine Control
System<11–3>
20A RADIO NO. 1
30A RADIO NO. 2
50A AM1
140A ALT
Short Pin
FL MAIN
3. 0W
Battery
(Shielded)
GND
CDL–
CDL+
CDR–
CDR+
TXM–
TXM+
MUTE
+B
ACC
SGND
L–
L+
R–
R+
TX–
TX+
ANT
BU
B–W
V
P
L–Y
W–G
W–L
R–L

53 LAND CRUISER / LAND CRUISER PRADO (Cont' d)

