



STARTING & CHARGING





0228Y–01

PREPARATION

SST

	09286–46011	Injection Pump Spline Shaft Puller	GENERATOR ASSY(1GR–FE)
	09820–63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY(1GR–FE)
	(09820–06010)	Alternator Rotor Shaft Wrench	GENERATOR ASSY(1GR–FE)
	(09820–06020)	Alternator Pulley Set Nut 22 mm Wrench	GENERATOR ASSY(1GR–FE)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	GENERATOR ASSY(1GR–FE)
	(09083–00150)	Test Lead Set	GENERATOR ASSY(1GR–FE)
	09904–00010	Expander Set	STARTER ASSY(1.6KW)(1GR–FE)
	(09904–00050)	No. 4 Claw	STARTER ASSY(1.6KW)(1GR–FE)

Equipment

Dial indicator with magnetic base	
Ohmmeter	
Pull scale	
Torque wrench	
V–block	
Vernier calipers	