IDENTIFICATION INFORMATION


010J5–02

VEHICLE IDENTIFICATION AND SERIAL NUMBERS


1. VEHICLE IDENTIFICATION NUMBER

(a) The vehicle identification number is the legal identifier for the vehicle. This number is stamped on the the front right side frame (except for GCC countries*) or on the top left of the instrument panel where it can be seen through the windshield from the outside (for GCC countries*), as shown in the illustration.
Except for GCC countries*:
This number is also stamped on the manufacture's plate.
For GCC countries*:
The year of manufacture and country of origin shown on the certification regulation label.
*: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait
A: Vehicle Identification Number
B: Manufacturer's Plate
C: Certification Regulation Label


Except for GCC Coutries*



D29304 D29303 D29296



For GCC Coutries*




D29308

2. ENGINE SERIAL NUMBER AND TRANSMISSION SERIAL NUMBER


(a) The engine serial number is stamped on the cylinder block of the engine, and the transmission serial number is stamped on the housing, as shown in the illustration.


Engine Serial Number



D30366 D29309

Transmission Serial Number





D30730