031DB–02

TORQUE SPECIFICATION

Part Tightened		N·m	kgf·cm	ft·lbf
Fuel delivery pipe sub–assy x Intake manifold		15	153	11
Intake air surge tank x Intake manifold		28	286	21
Intake air surge tank x Throttle body bracket		21	214	16
Intake air surge tank x Surge tank stay No. 1		21	214	16
Intake air surge tank x Surge tank stay No. 2		21	214	16
Fuel pressure regulator assy x Fuel delivery pipe sub–assy		9.0	92	80 in.·lbf
Fuel tank x Body		40	408	30
Fuel tank protector sub–assy No.1 x Body		20	204	15
Fuel tank plug x Fuel tank	3 door fuel tank 5 door fuel sub tank	6.5	66	57
Fuel tank to canister tube x Fuel tank	3 door fuel tank 5 door fuel sub tank	1.5	15	13
Fuel tank filler pipe x Fuel tank	3 door fuel tank 5 door fuel sub tank	3.0	31	27
Fuel suction tube w/ pump x Fuel tank	3 door fuel tank	3.5	36	31
Fuel sender gage x Fuel tank	3 door fuel tank 5 door fuel sub tank	1.5	15	13
Fuel tank vent tube x Fuel tank	5 door fuel sub tank	3.5	36	31
Fuel tank x Body		40	408	30
Fuel tank protector sub–assy No. 1 x Body	3 door fuel tank 5 door single tank	20	204	15
Fuel tank protector sub–assy No. 2 x Body	5 door fuel sub tank	20	204	15