CRUISE CONTROL SYSTEM (1GR–FE)

05ADI–03

HOW TO PROCEED WITH TROUBLESHOOTING

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–407)

3	CHECK AND CLEAR DTCS (See page 05–408)

4	PROBLEM SYMPTOM CONFIRMATION

- SYMPTOM DOES NOT OCCUR (GO TO STEP 5)
- SYMPTOM OCCURS (GO TO STEP 6)

5	SYMPTOM SIMULATION (See page 01–25)

6	DTC CHECK (See page 05–408)

- MALFUNCTION CODE (GO TO STEP 7)
- NORMAL CODE (GO TO STEP 8)

7	DTC CHART (See page 05–413)

GO TO STEP 9

8	PROBLEM SYMPTOMS TABLE (See page 05–416)

9	CIRCUIT INSPECTION (See page 05–417 – 05–428)

10	TERMINAL OF ECM (See page 05–415)

11	INDEMNIFICATION OF PROBLEM

12	REPAIR OR REPLACE

13	CONFIRMATION TEST

END

HINT:
Step 3, 6, 9, 13:
Diagnostic steps permit the use of the hand–held tester.