

FUEL TANK ASSY (1GR–FE(5DOOR))

COMPONENTS

110SF–01



SINGLE TANK




N·m (kgf·cm, ft·lbf): Specified torque

◆ Non–reusable part

A72583

DOUBLE TANK



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non–reusable part

A72585

A76695