





024BM–01

PREPARATION

SST

	09023–12701	Union Nut Wrench 17 mm	AUTOMATIC TRANSMISSION ASSY(A343F (2TR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1GR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1KD–FTV))
	09350–32014	TOYOTA Automatic Transmission Tool Set	AUTOMATIC TRANSMISSION ASSY(A343F (2TR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1GR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1KD–FTV))
	(09351–32010)	One–way Clutch Test Tool	AUTOMATIC TRANSMISSION ASSY(A343F (2TR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1GR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1KD–FTV))
	(09351–32020)	Stator Stopper	AUTOMATIC TRANSMISSION ASSY(A343F (2TR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1GR–FE)) AUTOMATIC TRANSMISSION ASSY(A750F (1KD–FTV))
	09843–18040	Diagnosis Check Wire No. 2	AUTOMATIC TRANSMISSION FLUID(A750F)

Recommended Tools

	09040–00011	Hexagon Wrench Set	TRANSMISSION WIRE(A750F) TRANSMISSION VALVE BODY ASSY(A750F)
	(09043–20100)	Socket Hexagon Wrench 10	TRANSMISSION WIRE(A750F) TRANSMISSION VALVE BODY ASSY(A750F)
	(09043–20060)	Socket Hexagon Wrench 6	AUTOMATIC TRANSMISSION FLUID(A750F)

Equipment

Straight edge	Torque converter
Vernier calipers	Torque converter
Dial indicator or dial indicator with magnetic base	Drive plate
Punch	
Torque wrench	

Lubricant

Item	Capacity	Classification
Automatic transaxle fluid (A343F) Dry fill Drain and refill	12.3 liters (13.0 US qts, 10.8 Imp.qts) 2.0 liters (2.1 US qts, 1.8 Imp.qts)	ATF Type T–IV
Automatic transmission fluid (A750F) Dry fill Drain and refill	10.9 liters (11.5 US qts, 9.6 Imp.qts) 3.0 liters (3.2 US qts, 2.6 Imp.qts)	ATF WS