05MX9–01

# PROBLEM SYMPTOMS TABLE

| Chart No. | Symptom | See page |
|---|---|---|
| 1 | Entire combination meter does not operate | 05–1562 (*1) |
| 2 | Malfunction in speedometer | 05–1562 (*1) |
| 3 | Malfunction in tachometer | 05–1568 (*1) |
| 4 | Malfunction in fuel receiver gauge | 05–1574 (*1) |
| 5 | Malfunction in water temperature receiver gauge | 05–1422 |
| 6 | Seat belt warning lamp for driver's seat does not operate | 05–1582 (*1) |
| 7 | Seat belt warning lamp for front passenger's seat does not operate | 05–1584 (*1) |
| 8 | Operating light control rheostat does not change light brightness | 05–1577 (*1) |
| 9 | Malfunction in average fuel consumption/instantaneous fuel consumption/possible running distance display | 05–1586 (*1) |
| 10 | The ambient temperature does not display | 05–1588 (*1) |
| 11 | Reverse shift warning buzzer does not sound | 05–1425 |

(*1): Refer to repair manual RM990E.