05G99–05

HOW TO PROCEED WITH TROUBLESHOOTING

NOTICE:

- **DTCs for the CAN communication system are as follows: U0073/94, U0123/62, U0124/95, U0126/63, U0100/65.**
- **Refer to troubleshooting of each system if DTCs regarding the CAN communication system are not output.**

1	**CHECK AND CLEAR DTCs**

NEXT

2	**CHECK CAN BUS LINE (SEE PAGE 05–1447)**

NEXT

3	**CHECK USING INTELLIGENT TESTER II**

(a) Select ”Communication Bus Check” (see page 05–1443).

Result:

A	All ECUs and sensors connected to the CAN communication system are displayed.
B	An ECU or sensor not connected to the CAN communication system is displayed.
C	A few ECUs or sensors not connected to the CAN communication system are displayed.

B → **COMMUNICATION STOP MODE TABLE (SEE PAGE 05–1436)**

C → **CHECK FOR AN OPEN IN ONE SIDE OF THE CAN SUB BUS LINE (SEE PAGE 05–1483)**

A

4	**DTC COMBINATION TABLE (SEE PAGE 05–1436)**

(a) Confirm trouble according to the combination of output DTCs regarding the CAN communication system.

HINT:

Previous CAN communication system DTCs may be the cause if CAN communication system DTCs are output and all ECUs and sensors connected to the CAN communication system are displayed on the intelligent tester II’s ”Communication Bus Check” screen.

NEXT

5	**CIRCUIT INSPECTION**

NEXT

6	**IDENTIFICATION OF PROBLEM**

NEXT

7	REPAIR OR REPLACE

NEXT

8	CONFIRMATION TEST

NEXT

END