

DIAGNOSTICS



PREPARATION



0220X–01

SST

	09243–00020	Idle Adjusting Screw Wrench	EFI SYSTEM(3RZ–FE(LEADED GASOLINE))
	09709–29018	LSPV Gauge Set	ABS WITH EBD & BA & TRC & VSC SYSTEM
	09816–30010	Oil Pressure Switch Socket	EFI SYSTEM(3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(UNLEADED GASOLINE))
	09843–18020	Diagnosis Check Wire	EFI SYSTEM(3RZ–FE(LEADED GASOLINE))
	09843–18040	Diagnosis Check Wire No.2	AIR CONDITIONING SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM TEMS & REAR AIR SUSPENSION SYSTEM ABS WITH EBD & BA & TRC & VSC SYSTEM ABS WITH EBD SYSTEM ECD SYSTEM(1KD–FTV) ECD SYSTEM(1KZ–TE) EFI SYSTEM(3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ECD SYSTEM(5L–E)
	09992–00242	Turbocharger Pressure Gauge	ECD SYSTEM(1KD–FTV) ECD SYSTEM(1KZ–TE) ECD SYSTEM(5L–E)

Recomended Tools

 09082–00040 TOYOTA Electrical Tester	SUPPLEMENTAL RESTRAINT SYSTEM COMBINATION METER ECD SYSTEM(1KD–FTV) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](1KD–FTV/1KZ–TE) ECD SYSTEM(1KZ–TE) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(UNLEADED GASOLINE)) ECD SYSTEM(5L–E)
 (09083–00150) Test Lead Set	AIR CONDITIONING SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM TEMS & REAR AIR SUSPENSION SYSTEM MULTIPLEX COMMUNICATION SYSTEM ABS WITH EBD & BA & TRC & VSC SYSTEM ENGINE IMMOBILISER SYSTEM WIRELESS DOOR LOCK CONTROL SYSTEM CRUISE CONTROL SYSTEM COMBINATION METER ABS WITH EBD SYSTEM POWER DOOR LOCK CONTROL SYSTEM KEY REMINDER WARNING SYSTEM ECD SYSTEM(1KD–FTV) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](1KD–FTV/1KZ–TE) ECD SYSTEM(1KZ–TE) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(UNLEADED GASOLINE)) ENGINE IMMOBILISER SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ECD SYSTEM(5L–E)

	09082–00050 TOYOTA Electrical Tester Set	POWER DOOR LOCK CONTROL SYSTEM
	(09083–00150) Test Lead Set	AIR CONDITIONING SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM TEMS & REAR AIR SUSPENSION SYSTEM MULTIPLEX COMMUNICATION SYSTEM ABS WITH EBD & BA & TRC & VSC SYSTEM ENGINE IMMOBILISER SYSTEM WIRELESS DOOR LOCK CONTROL SYSTEM CRUISE CONTROL SYSTEM COMBINATION METER ABS WITH EBD SYSTEM POWER DOOR LOCK CONTROL SYSTEM KEY REMINDER WARNING SYSTEM ECD SYSTEM(1KD–FTV) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](1KD–FTV/1KZ–TE) ECD SYSTEM(1KZ–TE) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(LEADED GASOLINE)) EFI SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT](3RZ–FE(UNLEADED GASOLINE)) ENGINE IMMOBILISER SYSTEM(3RZ–FE(UNLEADED GASOLINE)) ECD SYSTEM(5L–E)