

STARTING & CHARGING



0220B–01

PREPARATION

SST

	09286–46011	Injection Pump Spline Shaft Puller	STARTER ASSY(2.2KW)(1KZ–TE)
	09810–38140	Starter Magnet Switch Nut Wrench 14	STARTER ASSY(2.2KW)(1KZ–TE)
	09820–00030	Alternator Rear Bearing Replacer	STARTER ASSY(2.2KW)(1KZ–TE)

Recomended Tools

	09017–38120	Deep Socket Wrench 12 mm	GLOW PLUG ASSY(1KD–FTV) GLOW PLUG ASSY(1KZ–TE) GLOW PLUG ASSY(5L–E)
	09082–00040	TOYOTA Electrical Tester	STARTER ASSY(2.2KW)(1KZ–TE) STARTER ASSY (2.7KW)(1KZ–TE)

Equipment

Ammeter (A)	
Belt tension gauge	
Dial indicator	
Ohmmeter	
Press	
Pull scale	
Radiator cap tester	
Service wire harness	
Slide calipers	
Steel square	
Torque wrench	
V–block	
Vernier calipers	