TIRE & WHEEL

PREPARATION

021ZB–01

Equipment

Torque wrench	
Dial indicator with magnetic base	
Wheel balancer	