













DIFFERENTIAL











PREPARATION







021ZN–01











SST









	09023–00100	Union Nut Wrench 10 mm	DIFFERENTIAL CARRIER ASSY REAR
	09223–00010	Cover & Seal Replacer	DIFFERENTIAL CARRIER ASSY FRONT
	09223–15020	Oil Seal & Bearing Replacer	DIFFERENTIAL CARRIER ASSY FRONT
	09308–00010	Oil Seal Puller	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	09308–10010	Oil Seal Puller	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	09316–60011	Transmission & Transfer Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09316–00011)	Replacer Pipe	DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09316–00021)	Replacer "A"	DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09316–00041)	Replacer "C"	DIFFERENTIAL CARRIER ASSY REAR



	09330–00021	Companion Flange Holding Tool	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09330–00030)	Pin	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	09502–12010	Differential Bearing Replacer	DIFFERENTIAL CARRIER ASSY FRONT
	09504–00011	Differential Side Bearing Adjusting Nut Wrench	DIFFERENTIAL CARRIER ASSY REAR
	09506–30012	Differential Drive Pinion Rear Bearing Cone Replacer	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	09520–01010	Drive Shaft Remover Attachment	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT
	09520–24010	Differential Side Gear Shaft Puller	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT
	(09520–32040)	Shocker Set	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT
	09550–00032	Replacer	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL
	09554–22010	Differential Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY FRONT FRONT DIFFERENTIAL CARRIER OIL SEAL
	09554–30011	Differential Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL

	09556–22010	Drive Pinion Front Bearing Remover	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	09564–32011	Differential Preload Adaptor	DIFFERENTIAL CARRIER ASSY FRONT
	09608–32010	Steering Knuckle Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY FRONT
	09612–65014	Steering Worm Bearing Puller	DIFFERENTIAL CARRIER ASSY FRONT
	(09612–01020)	Claw "B"	DIFFERENTIAL CARRIER ASSY FRONT
	(09612–01050)	Hanger Pin with Nut	DIFFERENTIAL CARRIER ASSY FRONT
	09628–62011	Boll Joint Puller	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT
	09636–20010	Upper Ball Joint Dust Cover Replacer	DIFFERENTIAL CARRIER ASSY REAR
	09649–17010	Steering Knuckle Tool	DIFFERENTIAL CARRIER ASSY REAR
	09930–00010	Drive Shaft Nut Chisel	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09330–00030)	Pin	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL






	09950–00020	Bearing Remover	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09951–00680)	Replacer 68	DIFFERENTIAL CARRIER ASSY FRONT
	(09951–00890)	Replacer 89	DIFFERENTIAL CARRIER ASSY FRONT
	09950–30012	Puller A Set	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09951–03010)	Upper Plate	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09953–03010)	Center Bolt	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09954–03010)	Arm	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09955–03030)	Lower Plate 130	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL FRONT DIFFERENTIAL CARRIER OIL SEAL
	(09956–03020)	Adapter 18	DIFFERENTIAL CARRIER ASSY FRONT FRONT DIFFERENTIAL CARRIER OIL SEAL

	(09956–03030)	Adaptor 20	DIFFERENTIAL CARRIER ASSY REAR REAR DIFFERENTIAL CARRIER OIL SEAL
	09950–40011	Puller B Set	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09951–04020)	Hanger 200	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09952–04010)	Slide Arm	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09953–04020)	Center Bolt 150	DIFFERENTIAL CARRIER ASSY FRONT
	(09953–04030)	Center Bolt 200	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09954–04010)	Arm 25	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09955–04061)	Claw No.6	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09957–04010)	Attachment	DIFFERENTIAL CARRIER ASSY REAR
	(09958–04011)	Holder	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	09950–60010	Replacer Set	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09951–00360)	Replacer 36	DIFFERENTIAL CARRIER ASSY REAR
	(09951–00380)	Replacer 38	DIFFERENTIAL CARRIER ASSY REAR

	(09951–00430) Replacer 43	DIFFERENTIAL CARRIER ASSY REAR
	(09951–00470) Replacer 47	DIFFERENTIAL CARRIER ASSY REAR
	(09951–00480) Replacer 48	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09951–00510) Replacer 51	DIFFERENTIAL CARRIER ASSY FRONT
	(09951–00520) Replacer 52	DIFFERENTIAL CARRIER ASSY FRONT
	(09951–00550) Replacer 55	DIFFERENTIAL CARRIER ASSY REAR
	(09951–00610) Replacer 61	DIFFERENTIAL CARRIER ASSY FRONT
	09950–60020 Replacer Set No.2	DIFFERENTIAL CARRIER ASSY FRONT
	(09951–00680) Replacer 68	DIFFERENTIAL CARRIER ASSY FRONT
	(09951–00810) Replacer 81	DIFFERENTIAL CARRIER ASSY FRONT
	09950–70010 Handle Set	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	(09951–00560) Replacer 56	DIFFERENTIAL CARRIER ASSY REAR
	(09951–00570) Replacer 57	DIFFERENTIAL CARRIER ASSY REAR

	(09951–07100)	Handle 100	DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL
	(09951–07150)	Handle 150	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	09960–10010	Variable Pin Wrench Set	DIFFERENTIAL CARRIER ASSY REAR
	(09962–01000)	Variable Pin Wrench Arm Assy	DIFFERENTIAL CARRIER ASSY REAR
	(09963–00700)	Pin 7	DIFFERENTIAL CARRIER ASSY REAR

Recomended Tools

	09011–12301	Socket Wrench 30 mm	DIFFERENTIAL CARRIER ASSY FRONT DIFFERENTIAL CARRIER ASSY REAR
	09031–00030	Pin Punch	DIFFERENTIAL CARRIER ASSY FRONT
	09044–00010	Torx Socket E14	DIFFERENTIAL CARRIER ASSY FRONT
	09905–00012	Snap Ring No.1 Expander	DIFFERENTIAL CARRIER ASSY FRONT
	09905–00013	Snap Ring Pliers	DIFFERENTIAL CARRIER ASSY FRONT

Equipment

Dial indicator	
Micrometer	
Torque wrench	
Vernier calipers	
Press	

Lubricant

Item	Capacity	Classification
Front differential oil	1.40 ± 0.05 liters (1.48 ± 0.05 US qts, 1.23 ± 0.04 Imp.qts)	Hypoid gear oil APL GL–5 Above – 18°C (0°F): SAE 90 Below – 18°C (0°F): SAE 80W or 80W – 90
Rear differential oil : 3 Door : 4 pinion : w/LSD	2.5 ± 0.05 liters (2.64 ± 0.05 US qts, 2.68 ± 0.04 Imp.qts)	Hypoid gear oil APL GL–5 Above – 18°C (0°F): SAE 90 Below – 18°C (0°F): SAE 80W or 80W – 90
Rear differential oil : 3 Door : w/ Lock	2.4 ± 0.05 liters (2.54 ± 0.05 US qts, 2.68 ± 0.04 Imp.qts)	Hypoid gear oil APL GL–5 Above – 18°C (0°F): SAE 90 Below – 18°C (0°F): SAE 80W or 80W – 90
Rear differential oil : 5 Door : 4 pinion : w/LSD	3.05 ± 0.05 liters (3.22 ± 0.05 US qts, 2.68 ± 0.04 Imp.qts)	Hypoid gear oil APL GL–5 Above – 18°C (0°F): SAE 90 Below – 18°C (0°F): SAE 80W or 80W – 90
Rear differential oil : 5 Door : w/ Lock	2.95 ± 0.05 liters (3.12 ± 0.05 US qts, 2.68 ± 0.04 Imp.qts)	Hypoid gear oil APL GL–5 Above – 18°C (0°F): SAE 90 Below – 18°C (0°F): SAE 80W or 80W – 90