




AUDIO & VISUAL SYSTEM



PREPARATION

0220W–01

SST

	09950–50013	Puller C Set	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	(09951–05010)	Hanger 150	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	(09952–05010)	Slide Arm	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	(09953–05020)	Center Bolt 150	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	(09954–05021)	Claw No.2	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY

Recomended Tools

	09041–00030	Torx Driver T30	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	09042–00010	Torx Socket T30	ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY
	09070–20010	Moulding Remover	CIGARETTE LIGHTER ASSY RADIO RECEIVER ASSY MULTI–DISPLAY (CRT DISPLAY) DISPLAY ANTENNA CORD SUB–ASSY NAVIGATION ANTENNA ASSY AMPLIFIER ANTENNA ASSY POWER POINT SOCKET ASSY

Equipment

Torque wrench	