
IGNITER CIRCUIT

This A/C amplifier monitors the engine speed through signals sent from the igniter. The A/C amplifier uses these signals and compressor speed signals to detect the compressor lock condition.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	**CHECK OPERATION OF TACHOMETER**

NG → **GO TO COMBINATION METER SYSTEM**

OK

2	**CHECK HARNESS AND CONNECTOR(A/C AMPLIFIER – IGNITER)**

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE