NAVIGATION SYSTEM

0561A–04

HOW TO PROCEED WITH TROUBLESHOOTING

1	Vehicle Brought to Workshop

2	Customer Problem Analysis (See page 05–1479)

3	Problem Symptom Confirmation (See page 05–1510)

→ Symptom does not occur (Go to step 4)

→ Symptom occurs (Go to step 5)

4	Symptom Simulation (See page 01–26)

5	DTC Check (See page 05–1480)

→ Normal code (Go to step 7)

→ Malfunction code (Go to step 6)

6	DTC Chart (See page 05–1495)

Go to step 8

7	Problem Symptoms Table (See page 05–1510)

8	Terminal of ECU (See page 05–1506)

9	Indemnification of Problem

10	**Repair or Replace**

11	**Confirmation Test**

End