056QC–02

PROBLEM SYMPTOMS TABLE

Chart No.	Symptom	See page
1	Malfunction in speedometer	05–1560
2	Malfunction in tachometer	05–1566
3	Malfunction in water temperature receiver gauge	05–1569
4	Malfunction in fuel receiver gauge	05–1572
5	Operating light control rheostat does not charge light brightness	05–1575
6	Entire combination meter does not operate	05–1578
7	Seat belt warning lamp for driver's seat does not operate	05–1580
8	Seat belt warning lamp for front passenger's seat does not flash	05–1582
9	Malfunction in average fuel consumption/instantaneous fuel consumption/possible running distance display	05–1584
10	The ambient temperature does not display	05–1586