05ADW–01

DIAGNOSTIC TROUBLE CODE CHART

DTC No (See Page)	Detection Item	Trouble Area
B1221 (05–1601)	Power Window Switch Circuit on Driver Door	• Power window regulator master switch assy (D–door ECU)
B1231 (05–1602)	Jam Protection Limit Switch Circuit on Driver Door	• LHD: Power window regulator motor assy LH (Driver side) • RHD: Power window regulator motor assy RH (Driver side) • Wire harness • Power window regulator master switch assy (D–door ECU)
B1232 (05–1602)	Jam Protection Pulse Switch Circuit on Driver Door	