056Q3–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Only wireless control function does not operate (Prepare new or normal transmitter of the same type vehicle)	1. Transmitter battery 2. Door transmitter sub–assy module set door control 3. Door control receiver 4. Un–lock warning switch assy 5. Wire harness 6. Instrument panel J/B assy (Body ECU)	05–1708 73–26 05–1708 05–1708 – –
No answer–back (Hazard warning lamp)	1. Lighting system 2. Wire harness 3. Instrument panel J/B assy (Body ECU)	05–1336 – –