DTC	54	INPUT SIGNAL CIRCUIT MALFUNCTION

DTC	55	INPUT SIGNAL CIRCUIT MALFUNCTION

CIRCUIT DESCRIPTION

This DTC expresses the internal abnormalities of ECM.

DTC No.	Detection Item	Trouble Area
54 55	• Cruise control input signal abnormal. • Stop lamp switch input signal abnormal.	• ECM

INSPECTION PROCEDURE

1	CHECK AND REPLACE ECM (See page 01–36)