100BY–01

REPLACEMENT

1. REMOVE INTAKE PIPE

2. REMOVE INTAKE FLANGE

(a) Disconnect the ventilation hose.
(b) Disconnect the manifold absolute pressure sensor connector.
(c) Remove the 3 nuts, intake flange and gasket.

3. REMOVE VENTURI ASSY

(a) Disconnect the throttle open switch connector.
(b) Disconnect the throttle control motor connector.
(c) Remove the venturi and gasket.

4. INSTALL VENTURI ASSY

(a) Install a new gasket and venturi.
(b) Connect the throttle control motor connector.
(c) Connect the throttle open switch connector.

5. INSTALL INTAKE FLANGE

(a) Install a new gasket and intake flange with the 3 nuts.
Torque: 12 N·m (122 kgf·cm, 9 ft·lbf)
(b) Connect the manifold absolute pressure sensor connector.
(c) Connect the ventilation hose.

6. INSTALL INTAKE PIPE
Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)