

# FUEL TANK ASSY (5L–E(5DOOR))

## COMPONENTS

110MD–01



**SINGLE TANK**





N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non–reusable part

A72579

**DOUBLE TANK**




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non–reusable part

A72580