
50059–01



ON–VEHICLE INSPECTION

1. CHECK STEERING WHEEL FREEPLAY

(a) Park the vehicle and face the tires straight ahead.

(b) Rock the steering wheel gently up and down with your hand, check the steering wheel freeplay.

Maximum freeplay: 30 mm (1.18 in.)