
REAR COMBINATION LAMP LENS & BODY LH

650NM–01

REPLACEMENT



1. REMOVE REAR COMBINATION LAMP ASSY LH

(a) Disconnect the connector and remove the clamp.

(b) Remove the 3 nuts and rear combination lamp lens & body LH.

2. REMOVE REAR COMBINATION LAMP LENS & BODY LH

(a) Remove the socket and wire with 2 bulbs.

(b) Remove the rear combination lamp lens & body LH.