
CENTER STOP LAMP ASSY

REPLACEMENT

650NQ–01



1. REMOVE CENTER STOP LAMP ASSY

(a) Using a clip remover wrapped around with the protective tape, disengage the 4 claws on the bottom side.

(b) Disengage the 4 claws on the upper side and pull the center stop lamp assy.

(c) Disconnect the connector and remove the center stop lamp assy.