
HEADLAMP DIMMER SWITCH ASSY

650NR–01


REPLACEMENT

1. REMOVE STEERING COLUMN COVER(See page 50–6)



2. REMOVE HEADLAMP DIMMER SWITCH ASSY

(a) Disconnect the connector.



(b) Remove the 2 screws and headlamp dimmer switch assy.

3. INSTALL STEERING COLUMN COVER(See page 50–6)