

700O4–01

LOCATION

3–Door Models (LHD)




Instrument Panel J/B Assy (Body ECU)




B63194

3–Door Models (RHD)




Instrument Panel J/B Assy (Body ECU)




B64897

5–Door Models (LHD)




Instrument Panel J/B Assy (Body ECU)




B63195

5–Door Models (RHD)



Instrument Panel J/B Assy (Body ECU)



B64898