


# INSTRUMENT PANEL/METER

## COMPONENTS

710CT–01






Front Pillar Garnish LH
Assist Grip Assy
Front Pillar Garnish RH
20 (204, 14)
Instrument Panel Register Assy No.2
Instrument Panel Register Assy No.1
w/ Disc Player Changer:
Disc Player Changer w/ Bracket
Combination Meter Assy
Cowl Side Trim Board RH
Front Door Scuff Plate RH
Instrument Cluster Finish Panel Sub–Assy
Instrument Panel Finish Panel Lower No.2
Cowl Side Trim Board LH
LHD:
Front Floor Footrest
Instrument Panel Finish Plate
Instrument Panel Ornament
Instrument Cluster Finish Panel Ornament
Glove Compartment Door Sub–Assy
Instrument Panel Finish Lower Panel RH
Front Door Scuff Plate LH
Diesel Engine:
Instrument Panel Under Cover No.2
Turn Signal Switch Assy w/ Spiral Cable Sub–Assy
Instrument Panel Under Cover Sub–Assy No.1
Steering Wheel Assy
Steering Column Cover
Steering Wheel Cover Lower No.2
Steering Wheel Cover Lower No.3
Horn Button Assy
8.8 (90, 78 in.·lbf)
50 (510, 37)
N·m (kgf·cm, ft·lbf) : Specified torque
B63477



Defroster Nozzle Assy

Heater to Register Duct No.3







Instrument Panel Passenger Air Bag Assy

Side Defroster Nozzle No.1




**Auto Air Conditioner:**
Automatic Light Control Sensor





Antenna Code Sub–Assy




Connector No.2 Holder




Side Defroster Nozzle No.2


Instrument Panel Wire No.3

**w/ Navigation System:**
Navigation Antenna Assy





Instrument Panel Safety Pad Sub–Assy



Instrument Panel Bracket Sub–Assy Center

P

B64619