720F6–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Power seat does not operate	1. Front power seat switch 2. PWR SEAT fuse 3. Wire harness	72–5 68–1 –
Only slide operation function does not operate	1. Front power seat switch 2. Slide motor 3. Wire harness	72–5 72–5 –
Only front vertical operation function does not operate (Driver seat only)	1. Front power seat switch 2. Front vertical motor 3. Wire harness	72–5 72–5 –
Only lifter operetion function does not operate (Driver seat only)	1. Front power seat switch 2. Lifter motor 3. Wire harness	72–5 72–5 –
Only reclining operation function does not operate	1. Front power seat switch 2. Reclining motor 3. Wire harness	72–5 72–5 –
Only lumber support function does not operate (Driver seat only)	1. Power seat switch assy (Lumber support) 2. Reclining motor 3. Wire harness	72–5 72–5 –