720FH–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Seat heaters do not operate (Seat is not warmed up)	1. SEAT HEATER fuse	68–1
	2. IG 1 fuse	68–1
	3. IG relay	68–1
	4. Front seat cushion heater assy LH	72–26
	5. Front seat cushion heater assy RH	72–26
	6. Front seatback heater assy LH	72–26
	7. Front seatback heater assy RH	72–26
	8. Seat heater switch LH	72–26
	9. Seat heater switch RH	72–26
	10.Wire harness	–
Temperature of seat heater cannot be adjusted	1. Seat heater switch LH	72–26
	2. Seat heater switch RH	72–26
	3. Wire harness	–