
TRANSMITTER SUB–ASSY MODULE SET DOOR CONTROL

730EX–02

REPLACEMENT

HINT:

The installation is in the reverse order of the removal.



1. REMOVE TRANSMITTER SUB–ASSY MODULE SET DOOR CONTROL

NOTICE:

Special caution should be taken for handling each component as they are precise electronic components.

(a) Using a screwdriver, remove the screw.

(b) Push the cover with your finger, as shown in the illustration, so a gap appears, then pry out the cover using the gap.

NOTICE:

Do not forcibly pry the cover up.