7407E–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
AUTO function does not operate	1. Sliding roof motor assy	74–2
Sliding roof system does not operate	1. POWER fuse	–
	2. POWER relay	–
	3. Sliding roof housing assy	74–8
	4. Sliding roof motor switch assy	74–5
	5. Sliding roof motor assy	74–2
	6. Wire harness	74–5
Sliding roof system stops operation halfway	1. Sliding roof motor assy	74–2
	2. Wire harness	74–5
	3. Sliding roof housing assy	74–8