
BACK DOOR


COMPONENTS

750IQ–01

w/ Spare Tire




w/o Spare Tire




H

N·m (kgf·cm, ft·lbf) : Specified torque

B63768


w/ Spare Tire
w/ Inside Handle
Door Pull Handle Sub–assy
Back Door Inside Handle Assy
Back Door Outside Handle Cover LH
Back Door Handle Assy Outside LH
Back Door Outside Handle Pad Front
Back Door Outside Handle Frame Sub–assy LH
Back Door Outside Handle Pad Rear
Back Door Garnish Center
Damper Rubber
Back Door SIde Garnish RH
Back Door SIde Garnish LH
Hole Plug
Door Pull Handle Sub–assy
Back Door Side Female Stopper Sub–assy
Back Door Trim Board
5.0 (51, 44 in.·lbf)
◆ Door Dust Proof Seal
◆ Back Door Service Hole Cover RH
Rear Door Outside Handle Frame Sub–assy LH
Back Door Stopper Lower LH
Tool Box Bracket
Tool Set
◆ Door Lock Wire Harness Packing
Tool Cover
8.0 (82, 71 in.·lbf)
5.0 (51, 44 in.·lbf)
w/ Motor Back Door Lock Assy
w/ Inside Handle
Back Door Clamp
5.0 (51, 44 in.·lbf)
Screw x 7
Back Door Trim Pocket Sub–assy
w/ Motor Back Door Lock Assy
◆ Door Lock Wire Harness Packing
N·m (kgf·cm, ft·lbf) : Specified torque
◆ : Non–reusable part
B63665

w/o Spare Tire



N·m (kgf·cm, ft·lbf) : Specified torque

◆ : Non–reusable part

B63664