
CRUISE CONTROL MAIN SWITCH


8202T–01

REPLACEMENT

1. DISCONNECT BATTERY NEGATIVE TERMINAL (See page 60–1)
2. REMOVE STEERING WHEEL COVER LOWER NO.2
3. REMOVE STEERING WHEEL COVER LOWER NO.3
4. REMOVE HORN BUTTON ASSY (See page 60–14)



5. REMOVE CRUISE CONTROL MAIN SWITCH
   (a) Disconnect the connectors.
   (b) Remove the 2 screws and cruise control main switch.



6. INSTALL HORN BUTTON ASSY (See page 60–14)
7. INSPECT HORN BUTTON ASSY (See page 60–8)
8. INSPECT SRS WARNING LIGHT (See page 05–1122)