




LUBRICATION




PREPARATION

021YX–02

SST

	09950–60010	Replacer Set	OIL PUMP ASSY(3RZ–FE)
	(09951–00480)	Replacer 48	OIL PUMP ASSY(3RZ–FE)
	(09951–00710)	Replacer 71	OIL PUMP ASSY(3RZ–FE)
	(09952–06010)	Adapter	OIL PUMP ASSY(3RZ–FE)
	09950–70010	Handle Set	OIL PUMP ASSY(3RZ–FE)
	(09951–07100)	Handle 100	OIL PUMP ASSY(3RZ–FE)

Recomended Tools

	09904–00010	Expander Set	OIL PUMP ASSY(3RZ–FE)
	(09904–00040)	No. 3 Claw	OIL PUMP ASSY(3RZ–FE)
	09905–00013	Snap Ring Pliers	OIL PUMP ASSY(3RZ–FE)

Equipment

Feeler gauge	
Precision straight edge	
Torque wrench	