



STARTING & CHARGING


0220E–01

PREPARATION

SST

	09286–46011	Injection Pump Spline Shaft Puller	GENERATOR ASSY(3RZ–FE)
	09820–63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY(3RZ–FE)
	(09820–06010)	Alternator Rotor Shaft Wrench	GENERATOR ASSY(3RZ–FE)
	(09820–06020)	Alternator Pulley Set Nut 22 mm Wrench	GENERATOR ASSY(3RZ–FE)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	STARTER ASSY(3RZ–FE)

Equipment

V–block	
Dial indicator	
Ohmmeter	
Torque wrench	
Vernier calipers	
Slide calipers	
Press	