LUBRICATION

PREPARATION

0220D–01

Equipment

Feeler gauge	
Torque wrench	