
STARTING & CHARGING


021Z5–01

PREPARATION

SST

	09286–46011	Injection Pump Spline Shaft Puller	GENERATOR ASSY(5L–E)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	GENERATOR ASSY(5L–E) STARTER ASSY(5L–E)

Equipment

Dial indicator	
Press	
Pull scale	
Torque wrench	
V–blocks	
Vernier calipers	