




FUEL



PREPARATION

021ZG–01

SST

	09241–76022	Injection Pump Stand Set	INJECTION PUMP ASSY(1KZ–TE)
	09245–54010	Injection Pump Stand Arm	INJECTION PUMP ASSY(1KZ–TE)
	09260–54012	Injection Pump Tool Set	INJECTION PUMP ASSY(1KZ–TE)
	(09262–54010)	Distributor Head Plug Wrench	INJECTION PUMP ASSY(1KZ–TE)
	(09269–54020)	Socket 14 mm	INJECTION PUMP ASSY(1KZ–TE)
	09268–64010	Injection Nozzle Wrench Set	INJECTION NOZZLE SUB–ASSY(1KZ–TE)
	(09268–64020)	Injection Nozzle Holder Retaining Nut Wrench	INJECTION NOZZLE SUB–ASSY(1KZ–TE)
	(09268–64030)	Injection Nozzle Holder Wrench	INJECTION NOZZLE SUB–ASSY(1KZ–TE)

Recomended Tools

	09040–00011	Hexagon Wrench Set	INJECTION PUMP ASSY(1KZ–TE)
	(09043–20050)	Socket Hexagon Wrench 5	INJECTION PUMP ASSY(1KZ–TE)

Equipment

Brass brush	
Injection nozzle tester	
Torque wrench	
Wooden stick	