

2. NOTICE ABOUT VEHICLE CONDITION WHEN JACKING UP VEHICLE

for 3 Door:



for 5 Door:



: JACK POSITION

Front: Center of crossmember
Rear: Protruding part of rear suspension member

CAUTION:
When jacking up the vehicle, make sure the vehicle is not carrying any extra weight.

: SUPPORT POSITION

Swing arm type lift, Safety stand

F32725