



* 1:Cold Area Spec.
* 2:Except Cold Area Spec.
* 3:w/ Stop and Start System
* 4:w/o Stop and Start System


C180 Exhaust Fuel Addition Injector Assembly
C181 Nitrogen Oxides Sensor (Intake Side)
C182 Intake Air Temperature Sensor (Intercooler)
C183 E.F.I. Engine Coolant Temperature Sensor (Intercooler)
C191 Fuel Injector Assembly No. 1
C192 Fuel Injector Assembly No. 2
C193 Fuel Injector Assembly No. 3
C194 Fuel Injector Assembly No. 4
C195 Glow Plug Assembly
D 8 Starter Assembly
D 9 Starter Assembly
D 10 Starter Assembly
D 11 Starter Assembly
D 13 Starter Assembly
D 14 Starter Assembly
D 15 Starter Assembly
g 1 Front Television Camera Assembly
p 1 Front Speed Sensor RH
p 2 Front Speed Sensor LH
r 4 Viscous Heater with Magnet Clutch ASSY
r 5 Diesel Throttle Body ASSY
r 6 Injection or Supply Pump Assembly (Suction Control Valve)
r 7 Crank Position Sensor

C180
Gray




90980-12940

C181
Black



82824-60B00

C182
Black




82824-60B40

C183
White




90980-10735

C191
Gray




90980-12D50

C192
Gray




90980-12D50

C193
Gray




90980-12D50

C194
Gray



90980-12D50

C195
Gray



90980-12D51

D8



D9



D10
Black



90980-11184

D11
Black




90980-12941

D13




D14
Gray



90980-12669

D15
Black




90980-12C20

g1
Black




90980-12A59

p1
Black



90980-11900

p2
Black




90980-11900

r4
Gray




90980-11271

r5
Black



90980-11858

r6
Gray



90980-12747

r7
Black



90980-12353