

Instrument Panel Wire
Engine Wire
Engine Room Main Wire
Instrument Panel Wire Assembly
Roof Wire
Instrument Panel No.2 Wire
Engine Room Main Wire
G4
Front Door Wire LH
G3
Floor No.2 Wire
H1
Instrument Panel No.3 Wire
Front Door Wire RH
G5
Floor Wire
G1
Floor No.2 Wire
G2
Floor Wire