

Instrument Panel Wire
Engine Wire
Engine Room Main Wire
Instrument Panel Wire Assembly
Navigation Wire
H1
Roof Wire
Instrument Panel No. 2 Wire
Instrument Panel No. 3 Wire
Engine Room Main Wire
Front Door Wire RH
G4
G5
Front Door Wire LH
Floor Wire
G3
Floor No. 2 Wire
G1
Floor No. 2 Wire
G2
Floor Wire