

Roof Wire
Instrument Panel Wire Assembly
H1
Front Door Wire LH
G5
Switch Wire
Floor No. 2 Wire
Floor No. 2 Wire
Console Box Wire
Floor No. 9 Wire
Engine Room Main Wire
Engine Wire
Hazard Switch Wire
Instrument Panel Wire
Navigation Wire
Dash Wire
G4
Engine Room Main Wire
Instrument Panel No. 3 Wire
Front Door Wire RH
G3
G1
G2
Floor Wire
Instrument Panel No. 2 Wire
Floor Wire