



Position of Parts in Instrument Panel <LHD Front Separate Seat>




A 5 Stop Light Switch Assembly
A 11 Brake Pedal Load Sensing Switch
A 12 Skid Control Buzzer Assembly
A 13 Front Acceleration Sensor Assembly
A 14 Suspension Control ECU
A 19 Acceleration Sensor
A 40 Clutch Start Switch Assembly
A 41 Clutch Start Switch Assembly
A 43 Clutch Switch Assembly
A 49 Suspension Control ECU
A 54 Stop Light Control Relay Assembly
A 58 Headlight Swivel ECU Assembly
A 59 Diode (Stop Light)
A 64 Junction Connector
A 65 Junction Connector
A 66 Junction Connector
A 72 Junction Connector
A 73 Junction Connector
A 84 Diode (A/C COMP Relay)
A 85 Stop Light Switch Assembly
A 88 Diode (A/C COMP Relay)
C 34 ECM
C 35 ECM
C 36 ECM
C 37 ECM
C 47 Junction Connector
C 48 Junction Connector
C 49 Junction Connector
C 61 ECM
C 62 ECM
C 63 ECM
C 64 ECM
C 90 ECM
C 91 ECM
C 92 ECM
C 93 ECM
C101 ECM
C102 ECM
C136 Junction Connector
F 1 Front Passenger Side Squib Circuit

Position of Parts in Instrument Panel <LHD Front Separate Seat>




Position of Parts in Instrument Panel <LHD Front Separate Seat>


A65
White




A66
White



A72
White




A73
White



A84
Gray



A85
White




A88
Gray




Position of Parts in Instrument Panel <LHD Front Separate Seat>


C34
White




C35
White




C36
White




C37
White




C47
Black



C48
White




C49
Blue




Position of Parts in Instrument Panel <LHD Front Separate Seat>


C61
White




C62
White




C63
White




C64
White




C90
White




C91
White




C92
White



C93
White



C101
White



Position of Parts in Instrument Panel <LHD Front Separate Seat>

