


Position of Parts in Instrument Panel <RHD Front Separate Seat>




H 27	Radio Receiver Assembly
H 46	Radio Receiver Assembly
H 47	Radio Receiver Assembly
H 48	Radio & Display Receiver Assembly
H 49	Radio & Display Receiver Assembly
H 50	Radio & Display Receiver Assembly
H 51	Radio & Display Receiver Assembly
H 52	Radio & Display Receiver Assembly
H 53	Navigation Receiver Assembly
H 54	Navigation Receiver Assembly
H 55	Navigation Receiver Assembly
H 56	Navigation Receiver Assembly
H 57	Navigation Receiver Assembly
H 58	Navigation Receiver Assembly
H 63	Stereo Component Amplifier Assembly
H 64	Stereo Component Amplifier Assembly
H 65	Stereo Component Amplifier Assembly
H 66	Stereo Component Amplifier Assembly
H 67	Stereo Component Amplifier Assembly
H 68	No. 1 Stereo Jack Adapter Assembly
H 69	Radio & Display Receiver Assembly
H 70	No. 1 Stereo Jack Adapter Assembly

Position of Parts in Instrument Panel <RHD Front Separate Seat>


H27
White




H46
White




H47
White




H48
White




H49
White



H50
White



H51
White




H52
White




H53
White




H54
White




H55
White




H56
White




H57
White



H58
Gray




H63
White




H64
White




H65
White




H66
White




H67
White



H68
Black



H69
Gray



H70
Black

