

Component	Pin	Wire Color	Notes
Air SUS Relay	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground
Air SUS Solenoid Valve	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground
Height Control Compressor Motor	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground
Height Control Exhaust Valve	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground
Height Control Valve	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground
Shift Position Indicator	1	W-B	Ground
	2	W-B	Ground
	3	W-B	Ground
	4	W-B	Ground

*1 :w/o Drive Mode Select Switch

M

