



 Instrument Panel J/B Assembly (Before Aug. 2017 Production)	LHD : Cowl Side Panel LH
	RHD : Cowl Side Panel RH




F RELAY LOCATIONS

View A




View B



F RELAY LOCATIONS

View C


* 1:15A (Before Aug. 2013 Production)
10A (From Aug. 2013 Production)



F RELAY LOCATIONS


 Instrument Panel J/B Assembly (From Aug. 2017 Production)	LHD : Cowl Side Panel LH
	RHD : Cowl Side Panel RH

(Except 5L-E)




F RELAY LOCATIONS

View A




View B



F RELAY LOCATIONS


View C

*1: 10A S&S IG2(w/ Door Control Battery)




 Instrument Panel J/B Assembly (From Aug. 2017 Production)	LHD : Cowl Side Panel LH
	RHD : Cowl Side Panel RH

(5L-E)




F RELAY LOCATIONS

View A



View B



F RELAY LOCATIONS

View C

* 1:15A (Before Aug. 2013 Production)
10A (From Aug. 2013 Production)

