


Position of Parts in Engine Compartment (LHD 1GD-FTV) (w/ Water-cooled Intercooler From Jun. 2018 Production)



- C164 Generator Assembly
- C165 Glow Plug Assembly
- C166 No. 2 Exhaust Gas Temperature Sensor
- C167 No. 3 Exhaust Gas Temperature Sensor
- C168 Urea Injector Assembly
- C169 No. 1 Exhaust Gas Temperature Sensor
- C170 Cam Position Sensor
- C171 Engine Oil Level Sensor
- C172 Intake Mass Air Flow Meter Sub-Assembly
- C173 VSV (for Engine Mounting)
- C175 DC Motor
- C176 Intake Air Temperature Sensor (Turbo)
- C177 Transmission Revolution Sensor (Counter Gear)
- C178 Transmission Revolution Sensor (Turbine)
- C179 Vane Pump Assembly
- C180 Exhaust Fuel Addition Injector Assembly
- C181 Nitrogen Oxides Sensor (Intake Side)
- C182 Intake Air Temperature Sensor (Intercooler)
- C183 E.F.I. Engine Coolant Temperature Sensor (Intercooler)
- D 8 Starter Assembly
- D 9 Starter Assembly
- D 10 Starter Assembly
- D 11 Starter Assembly
- g 1 Front Television Camera Assembly
- p 1 Front Speed Sensor RH
- p 2 Front Speed Sensor LH
- r 4 Viscous Heater with Magnet Clutch ASSY
- r 5 Diesel Throttle Body ASSY
- r 6 Injection or Supply Pump Assembly (Suction Control Valve)
- r 7 Crank Position Sensor
- r 8 Fuel Pressure Sensor (Common Rail Assembly)
- r 9 Pressure Discharge Valve (Common Rail Assembly)

