


Position of Parts in Engine Compartment (RHD 1KD-FTV) (From Aug. 2017 Production)



- A 1 Ambient Temperature Sensor
- A 2 A/C Pressure Sensor
- A 4 Condenser Fan Motor (With Shroud Blower Assembly)
- A 7 Brake Actuator Assembly
- A 8 Brake Actuator Assembly
- A 20 Front Airbag Sensor RH
- A 21 Front Airbag Sensor LH
- A 22 Windshield Wiper Motor Assembly
- A 23 Windshield Washer Motor and Pump Assembly
- A 24 Low Pitched Horn Assembly
- A 25 High Pitched Horn Assembly
- A 26 Security Horn Assembly
- A 27 Engine Hood Courtesy Switch
- A 37 Headlight Cleaner Motor and Pump Assembly
- A 38 Headlight Cleaner Control Relay
- A 39 Wireless Door Lock Buzzer
- A 47 Short Connector
- A 48 Short Connector
- A 56 Front Absorber Control Actuator RH
- A 57 Front Absorber Control Actuator LH
- A 68 Junction Connector
- A 70 Junction Connector
- A 75 Level Warning Switch (Fuel Filter Assembly)
- A 76 Fuel Filter Warning Switch
- A 77 Fuel Heater Assembly
- A 90 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)

Position of Parts in Engine Compartment (RHD 1KD-FTV) (From Aug. 2017 Production)

